


# Clearaudio Concept – speed adjustment

Please note- information below applies to Concept models produced prior to 2015. For more recent production Concepts, adjustment is performed with the 3 potentiometers located at the rear of the unit and a standard slotted screwdriver. More info can be found in your manual.

1. Always begin with adjusting 33 1/3 rpm (No. 1 in the drawing)
2. Use a non-metal slotted screwdriver (plastic / ceramic) for the 33 1/3 speed adjustment
3. Use a slotted screwdriver to adjust the potentiometers used for 45 rpm (#2) and 78 rpm (#3)
4. The turntable must be level when adjusting the speed. (Place the turntable over the edge of a table to reach the pots from below)



Note: Concepts below serial-no.: 0530678 use a small hex key wrench to adjust 45 and 78 rpm.

Tel. 510 547-5006, email [info@musicalsurrroundings.com](mailto:info@musicalsurrroundings.com)